

TEMPLATE PIECES



SKIVE WIDTH (1.5 cm)

After skiving, roll (fold and glue) the edge down and stitch across the edge to keep leather from unfolding.
Make the stitch 1cm from the edge.

If you do not wish to roll the edge, simply trim across the dotted line.

OUTER POCKET

(1cm wider than middle pocket)

