





Use 1" buckles for the straps.

The bag may be placed in the center of the bike frame using 5 longer straps, forward in the frame using 4 short straps, or back toward the seat using 3 short straps.



©2020 Tony Allen Bernier

For a complete breakdown of the process check out my YouTube channel. Type in Tony Allen Bernier to find my channel, or use this address.

<https://www.youtube.com/channel/UCdQOVdzUtqzgRSxP2jpTu3A/videos>

Make sure to click the video tab to see all my video's. Subscribe to my channel for updates on new and free patterns, giveaways, and instructional videos.

To print on a home printer select 100% or true to scale (depending on your printer/software). Another setting that sometimes gets overlooked is the poster setting. For some printers/software you'll need to select that as well so that all the pages get printed. You may also need to select "separate pages to multiple sheets" before you are allowed to select print at 100%.


(When printing patterns on an A4 printer, if the pattern doesn't already have a separate A4 file, printing with landscape at 100% may fix any issues you have. You may also want to decrease your margins to the minimum.)

Copyright Notice


My patterns are not to be redistributed (sold or given) in any way shape or form. Except for the class rule written below, Or when a wholesale order has been accepted and terms have been agreed upon.

Any **Items** made using my patterns may be sold through any form of shop, online or otherwise. For every 10 items sold for each separate pattern I require you to purchase an additional copy of the pattern to cover my designer copyrights. If you wish to use my patterns in a workshop/class you must purchase a copy of said pattern for each student attending plus one for the instructor. By purchasing this pattern you agree to the terms herein. If these rules are abused, actions will be taken.

www.Etsy.com/shop/TonyAllenBernier



Start either end of gusset at this mark





Note on Center mo

If you plan on mounting the bag in the c

If you plan on mounting it close to th


mounting it back toward






mounting options.

center of the frame, use all five long straps.
the front use 4 short straps. If you plan on
rd the seat use 3 short straps.







See note on center
mounting options

Stop on these holes if you decide not to stitch
around the whole perimeter of the strap




Start either end of gusset at this mark






Stop on these holes if you decide not to stitch
around the whole perimeter of the strap








See note on center
mounting options





See note on center mounting options




Gusset panel measurements
are mirrored, you can start
either end at the starting
point on the side panels







Stop on these holes if you decide not to stitch around the whole perimeter of the strap





Cut two of these if you're making the zipper cover shown in the video for this project. If you're doing the version shown in my Hummingbird purse video cut only one of these out.



This part should be 2-4oz chrome tan.