





Printing Instruction

1. File > Print
2. Click on “Page Setup” button make sure your paper size is set to A4 and Scale at 100%
3. In “Pages Sizing & Handling” click on “Size” button and select “Actual size”





CraftsmanGus



Card Zipper Wallet

Page 1 of 2



CraftsmanGus

CraftsmanGus : Pattern

Standard : Zipper Card Holder

Wal H01 #4mm.

Main Interior

0.8 mm. REC

WAL CZ/ O4

X 1

CraftsmanGus : Pattern

Standard : Zipper Card Holder

Wal H01 #4mm.

Cover

1.5-1.8 mm. REC

*Zipper No.#5 or closest size

WAL CZ/ O5

X 1