



DRAWBRIDGE PROPS & ARMOURY

LEATHER LIGHTER KNUCKLES



INSTRUCTIONS:

1. Print pattern - check scale using 2" box
2. Cut out paper pattern and trace on leather
3. Cut leather to shape
4. Add desired tooling and let dry
5. Glue to final shape
6. Sand edges smooth
7. Bevel edges if desired
8. Punch stitching holes along dashed line
9. Dye and apply finish
10. Stitch around dashed line
11. Burnish edges


PATTERN CREATED BY: LEVI WOODS

VIDEO DEMO: [YOUTUBE.COM/DRAWBRIDGEPROPS_AND_ARMOURY](https://www.youtube.com/DrawbridgeProps_and_Armoury)

© DRAWBRIDGE ENTERTAINMENT INC

DRAWBRIDGE PROPS & ARMOURY

LEATHER LIGHTER KNUCKLES




MATERIALS:

Leather (6 - 9 oz or 2.4 mm - 3.6 mm thick)
Thread
Contact Cement or Glue
Coloured Dye or Paint
Leather Finish

TOOLS:

Utility Knife
Brushes or daubers
Hole Punch or Drill
Pen
Needles
Dremel or Sandpaper
Swivel Knife (Optional)
Hammer or Maul (Optional)
Leather Stamps (Optional)



PATTERN CREATED BY: LEVI WOODS

VIDEO DEMO: [YOUTUBE.COM/DRAWBRIDGEPROPS_AND_ARMOURY](https://www.youtube.com/DrawbridgeProps_and_Armoury)

© DRAWBRIDGE ENTERTAINMENT INC