




PRINTING INSTRUCTION

1. File > Print
2. Click on “Page Setup” button make sure your paper size is set to the paper size that you will print and Scale at 100%
3. In “Pages Sizing & Handling” click on “Size” button and select “Actual size”





IMPORTANT NOTE:

- **ADOBE ACROBAT READER (FREE SOFTWARE)** is recommended to open and print the patterns


link for free download

<https://get.adobe.com/reader>








Gus : Pattern



anned 1.8 mm. REC


X 1



Zipper Opening Side -->(Open)



Gus : Pattern






anned 1.8 mm. REC

X 1



CraftsmanGus : Pattern

Dopp Kit
SML DK 01
Main Body
Chrome / Veg Tanned 1.8 mm. REC



(Close)<--- Zipper Opening Side



CraftsmanGus : Pattern
Dopp Kit
SML DK 01
Main Body
Chrome / Veg Tanned 1.8 mm. REC