

190 mm (7.48 inches)

THIS IS THE TEST PAGE

Make sure these dimensions are correct
before cutting out your pattern.

HOW TO PRINT THE PATTERN CORRECTLY:

STEP 1: Go to FILE -> PRINT

STEP 2: Go to PAGE SETUP and choose size: A4 or Letter

STEP 3: Make sure ACTUAL SIZE is checked

**STEP 4: Click PRINT to get your patterns
at the intended size**

250 mm (9.84 inches)


60 mm (2.36 inches)

80 mm (3.14 inches)

80 mm (3.14 inches)



RUSTY RHINO





○ ○

○ ○

○ 1A ○

○ ○

○ ○

○ ○

○ ○

○ 1A ○

○ ○



○ ○







1A

1A







2A

2A

2A



2A

2A

2A

○

○

○

3A

○

○

○

○

○

○

3A

○

○

○

○

○

○

3A

○

○

○

○

○

○

3A

○

○

○

○

○

○

3A

○

○

○

○

○

○

3A

○

○

○

○

○

○

3A

○

○

○

○

○

○

3A

○

○

○

○
○
○
3A
○
○
○

○
○
○
3A
○
○
○

○
○
○
3A
○
○
○

○
○
○
3A
○
○
○

