


Number of needed
pieces of each pattern
is shown with a star. *

Attention : This line length should be 240 mm after printing

1 *

#1 Front
Right




Attention : This line length should be 180 mm after printing



contact us : EchoPic.au@gmail.com


Attention : This line length should be 240 mm after printing



Attention : This line length should be 180 mm after printing



contact us : EchoPic.au@gmail.com



Attention : This line length should be 240 mm after printing

Attention : This line length should be 180 mm after printing




contact us : EchoPic.au@gmail.com

Attention : This line length should be 240 mm after printing

#2 Back
Right


*1



Attention : This line length should be 180 mm after printing





contact us : EchoPic.au@gmail.com



Attention : This line length should be 240 mm after printing

Attention : This line length should be 180 mm after printing

#6 1st pocket zipper *1



Attention : This line length should be 240 mm after printing

Attention : This line length should be 180 mm after printing



#5 snap holder

#5

2nd pocket door

*1

#4

*1

2nd pocket



Attention : This line length should be 240 mm after printing

Attention : This line length should be 180 mm after printing





Attention : This line length should be 240 mm after printing

joint edge



joint edge



Attention : This line length should be 180 mm after printing

